


# NON-COHESIVE SLOPE DETAIL



**NOTES:**

1. ATTACH SCOUR STOP WITH ANCHOR USING FLEXIBLE STRAP AND PUSH ON ONE-WAY STOP 18" MIN. (INSTALL ANCHORS UP TO 36" DEEP, IF NEEDED TO REACH FIRM SOIL).
  
2. AREA ABOVE THE WAVE ACTION MAY BE COVERED WITH SOD, A SOIL-FILLED HIGH-PERFORMANCE TRM OVER A GEOTEXTILE, OR SOD COVERED WITH AN OPEN-WEAVE TRM STRETCHED TIGHTLY ACROSS THE VEGETATION.